

EN HEAT PUMPS for above and inground pools

IT POMPA DI CALORE per piscine fuori terra e interrata


ES BOMBAS DE CALOR para piscinas sobre suelo y enterradas

NL WARMTEPOMP voor verwijderbare en ingebouwde zwembaden

FR POMPES À CHALEUR pour piscines hors sol et enterrées

PT BOMBAS DE CALOR para piscinas elevadas e enterradas





DE WÄRMEPUMPE für Aufstell-und Einbaubecken



Owner's Manual - Manual de Instrucciones
Manuel d'instructions - Bedienungsanleitung
Manuale delle istruzioni
Handleiding met instructies
Manual de instruções

English manual.....	1~33
Manual en Español	34~68
Notice en Français.....	69~103
Deutsches Handbuch.....	104~137
Manuale Italiano.....	138~172
Netherland manual.....	173~206
Manual Português.....	207~240
Warranty.....	241~245

 **WARNINGS**

	<p>This symbol shows that information is available such as the Operating Manual or Installation Manual.</p>		<p>This symbol shows that this appliance uses R32, a low burning velocity refrigerant.</p>
	<p>This symbol shows that the Operation Manual should be read carefully.</p>		<p>This symbol shows that service personnel should be handling this equipment with reference to the Installation Manual.</p>

GENERAL WARNINGS

- Failure to respect the warnings may cause serious damage to the pool equipment or cause serious injury, even death.
- Only a person qualified in the technical fields concerned (electricity, hydraulics or refrigeration) is authorised to carry out maintenance or repair work on the appliance. The qualified technician working on the appliance must use/wear personal protective equipment (such as safety goggles and protective gloves, etc.) in order to reduce the risk of injury occurring when working on the appliance.
- Before handling the appliance, check that it is switched off and isolated.
- This appliance is not intended for use by individuals (including children, over the age of 8) lacking in experience or with impaired physical, sensory or mental capabilities, unless: they receive supervision and are instructed on how to use the appliance by a person responsible for their safety; and if they understand the hazards involved.
- Children must be supervised to ensure that they do not play with the appliance.
- The appliance must be installed according to the manufacturer’s instructions and in compliance with local and national standards. The installer is responsible for installing the appliance and for compliance with national installation regulations. Under no circumstances may the manufacturer be held liable in the event of failure to comply with applicable local installation standards.
- For any work other than the simple user maintenance described in this manual, the product should be referred to a qualified professional.
- Incorrect installation and/or use may cause serious damage to property or serious injuries (possibly causing death).
- If the appliance suffers a malfunction, do not try to repair it yourself; instead contact a qualified technician.
- Deactivating, eliminating or by-passing any of the safety mechanisms integrated into the appliance shall automatically void the warranty, in addition to the use of spare parts manufactured by unauthorised third-party manufacturers.
- Do not spray insecticide or any other chemical (flammable or non-flammable) in the direction of the appliance, as this may damage the body and cause a fire.
- Do not touch the fan or moving parts and do not place objects or your fingers in the vicinity of the moving parts when the appliance is in operation. Moving parts can cause serious injury or even death.

WARNINGS ASSOCIATED WITH ELECTRICAL APPLIANCES

- The power supply to the appliance must be protected by a dedicated 30 mA Residual Current Device (RCD), complying with the standards and regulations in force in the country in which it is installed.
- Do not use any extension lead when connecting the appliance; connect the appliance directly to a suitable power supply.
- Before carrying out any operations, check that:
 - The voltage indicated on the appliance information plate corresponds to the mains voltage.

-The power grid must be adapted to the power requirements of the appliance, and is grounded.

- Do not disconnect and reconnect the appliance to the power supply when in operation.
- Do not pull on the power cord to disconnect it from the power supply.
- If the power cord is damaged, it must be replaced by the manufacturer, its technician or a qualified person to guarantee safety.
- Do not perform maintenance or servicing operations on the appliance with wet hands or if the appliance is wet.
- Before connecting the appliance to the power supply, check that the connection unit or socket to which the appliance will be connected is in good condition and shows no signs of damage or rust.
- In stormy weather, disconnect the appliance from the power supply to prevent it from suffering lightning damage.
- Do not immerse the appliance in water or mud.

WARNINGS CONCERNING APPLIANCES CONTAINING REFRIGERANT R32

- R32 refrigerant is classed under category A2L as mildly flammable.
- Do not release R32 fluid into the atmosphere. These are fluorinated greenhouse gases, covered by the Kyoto Protocol, with a Global Warming Potential (GWP) of 675 (European regulation EU 517/2014).
- The appliance must be stored in a well-ventilated location away from all ignition sources.
- Install the unit outdoors. Do not install the unit indoors or in an enclosed and non-ventilated outdoor location.
- Do not use means for accelerating the defrosting or cleaning process other than those recommended by the manufacturer.
- The appliance must be stored in a room without any permanent ignition source (such as open flames, operating gas appliance or operating electric heating).
- Do not perforate or incinerate.
- Please note that R32 refrigerant may give off a certain odour.
- In order to comply with the applicable standards and regulations in terms of the environment and installation, in particular French decree No. 2015-1790 and/or European regulation EU 517/2014, a leak test must be performed on the cooling circuit at least once a year. This operation must be carried out by a specialist certified to test cooling appliances.
- Please keep the display controller in a dry area, or well close the insulation cover to protect the display controller from being damaged by humidity.

INSTALLATION AND MAINTENANCE

- The appliance may not be installed close to combustible materials, or the air duct inlet of an adjacent building.
- With some appliances, it is essential to fit a "protection grid"-type accessory if the unit is installed in an area with uncontrolled access.
- During installation, troubleshooting and maintenance, pipes may not be used as steps: the pipe could break under the weight, spilling refrigerant and possibly causing serious burns.
- When servicing the appliance, the composition and state of the heat transfer fluid must be checked, as well as the absence of any traces of refrigerant.
- During the annual appliance sealing test in accordance with applicable legislation, the high and low pressure switches must be checked to ensure that they are securely fastened to the refrigerant circuit and that they cut off the electrical circuit when tripped.
- During maintenance work, ensure there are no traces of corrosion or oil around the cooling components.
- Before beginning work on the cooling circuit, stop the appliance and wait for a few minutes before fitting the temperature and pressure sensors. Some elements such as the compressor and piping may reach temperatures in excess of 100°C and high pressures with the consequent risk of severe burns.
- Do not braze or weld the pipe if there is refrigerant inside machine. Please do not charge the gas when in a confined space.

MAINTENANCE : WARNINGS CONCERNING APPLIANCES CONTAINING R32 REFRIGERANT

Area check

- Before starting work on systems containing flammable refrigerants, safety checks must be carried out to guarantee a minimal ignition risk.

Work procedure

- The work must be carried out according to a controlled procedure in order to reduce the risks of releasing a flammable gas or vapour while working.

General work area

- All maintenance staff and other personnel working in the surrounding area must be made aware of the work carried out. Work conducted in enclosed areas must be avoided.

Check for the presence of refrigerant

- The area must be analysed using a suitable refrigerant detector before and during work so that the technician is informed of the presence of a potentially toxic or flammable atmosphere. Check that the leak detection equipment used is suitable for use with all refrigerants concerned, i.e. that it does not cause a spark, is correctly isolated or is entirely safe.

Check for the presence of a fire extinguisher

- If work must be carried out on the cooling equipment or any part associated therewith at a certain temperature, suitable fire extinguishing means must be within reach. Place a dry chemical fire extinguisher or CO₂ fire extinguisher near the work area.

No source of ignition

- No person carrying out work on a cooling system involving exposing the piping may use any ignition source, which could create a fire or explosion risk. All possible ignition sources, in particular cigarettes, must not enter within a sufficient perimeter of the installation, repair, removal or disposal site, in the event that refrigerant could be released into the surrounding space. Before starting the work, the area around the equipment must be examined to check for all fire or ignition risks. "No smoking" signs must be displayed.

Area ventilation

- Before accessing the unit in any manner whatsoever with the intention of performing any maintenance task, check that the area is open and well-ventilated. Suitable ventilation must be provided throughout the maintenance task to allow any refrigerant that could be released into the atmosphere to be safely dispersed.

Refrigeration equipment check

- The manufacturer's recommendations in terms of care and maintenance must always be complied with. When replacing electric components, check that components used are of the same type and category as those recommended/approved by the manufacturer. When in doubt, contact the manufacturer's technical department for assistance.
- The following checks must be applied to installations using flammable refrigerants:
 - the markings on the equipment must remain visible and legible; any illegible markings or signs must be rectified;
 - the hoses or components of the cooling circuit are installed in a position where they are unlikely to be exposed to any substance capable of corroding the components containing refrigerant, unless the components are made from materials that are typically corrosion-proof or correctly protected from such corrosion.

Electric component check

- The repair and maintenance of electric components must include initial safety checks and component inspection procedures. If a defect capable of jeopardising safety arises, no power supply must be connected to the circuit until the problem has been completely resolved. If the defect cannot be rectified immediately and if

maintenance work must continue, an appropriate temporary solution must be found. This must be reported to the equipment's owner so that all persons concerned are made aware.

- The repair and maintenance of electric components must include the following initial safety checks:

- the capacitors are discharged: this must be carried out safely to prevent all risks of ignition;
- no electric component or live wiring is exposed while charging, overhauling or draining the system;
- the system must be grounded at all times.

Repair of insulated components

- When repairing insulated components, all power sources must be disconnected from the equipment on which the work is being carried out before removing the insulating cover, etc. If the equipment must be powered during maintenance work, a leak detector must continuously monitor for leaks at the most critical point in order to report any potentially hazardous situation.
- Particular attention must be paid to the following points to ensure that, when performing work on the electric components, the housing is not altered to the point of affecting the protection rating. This includes damaged wires, an excessive number of connections, terminals that do not comply with the original specifications, damaged seals, incorrect installation of the cable glands, etc.
- Make sure that the appliance is properly fixed.
- Make sure that the seals or insulating materials are not deteriorated to the point that they no longer prevent a flammable atmosphere from penetrating the circuit. Spare parts must be compliant with the manufacturer's specifications.

Repair of intrinsically safe components

- Do not apply any permanent electric capacitance or induction charge to the circuit without checking that it does not exceed the allowed voltage and intensity for the equipment being used.
- Typically safe components are the only types on which work can be carried out in the presence of a flammable atmosphere when live. The test appliance must fall under a suitable classification.
- Only replace components with parts specified by the manufacturer. Other parts could cause the refrigerant to leak and ignite in the atmosphere.

Wiring

- Check that the wiring shows no signs of wear, corrosion, excessive pressure, vibration, cutting edges or any other detrimental environmental effect. The check must also take into account the effects of ageing or continuous vibrations caused by sources such as compressors or fans.

Detection of flammable refrigerant

- Under no circumstances must potential ignition sources be used to search for or detect refrigerant leaks. A halide torch (or any other detector using a naked flame) must not be used.
- The following leak detection methods are considered to be acceptable for all cooling systems.
- Electronic leak detectors can be used to detect refrigerant leaks; however, in the case of flammable refrigerants, the sensitivity level may not be suitable or recalibration may be necessary. (The detection equipment must be calibrated in an area devoid of refrigerant). Check that the detector is not a potential ignition source and is appropriate for the refrigerant used. The leak detection equipment must be adjusted to a percentage of the refrigerant's LFL and must be calibrated according to the refrigerant used. The appropriate gas percentage (25% at most) must be confirmed.
- Leak detection fluids are also suited for use with most refrigerants, however the use of detergents containing chlorine must be avoided since it could react with the refrigerant and cause corrosion to the copper piping.
- If a leak is suspected, all naked flames must be removed/extinguished.
- If a refrigerant leak is detected and requires soldering, the entire quantity of refrigerant must be removed from the system or isolated (by way of shut-off valves) in part of the system located away from the leak.

Removal and discharge

- When accessing the cooling circuit to carry out repairs, or for any other reason, conventional procedures must be employed. However, for flammable refrigerants, the recommendations must be complied with in order to take account of the product's flammability. The following procedure must be followed:
- remove the refrigerant;
- purge the circuit with an inert gas (optional for A2L);
- drain (optional for A2L);
- purge with an inert gas (optional for A2L);
- open the circuit by cutting or soldering.
- The refrigerant charge must be recovered in suitable recovery cylinders. For appliances containing flammable refrigerants other than A2L refrigerants, the system must be bled with nitrogen devoid of oxygen to make the appliance suitable for receiving flammable refrigerants. You may need to repeat this process several times. Compressed air or oxygen must not be used to purge cooling systems.

Loading procedures

- Check that the vacuum pump outlet is not located in the vicinity of any potential ignition source and that ventilation is provided.
- In addition to conventional charging procedures, the following requirements apply.
- Check that there is no possibility of cross-contamination between the different refrigerants when using charging equipment. Hoses or lines must be as short as possible to reduce the quantity of refrigerant contained therein.
- Cylinders must be kept in an appropriate position, in accordance with the instructions.
- Check that the cooling system is grounded before charging the system with refrigerant.
- Label the system once charging is complete (if this is not already the case).
- Pay close attention to not overfilling the cooling system.
- Before recharging the system, carry out a pressure test using a suitable purge gas. The system must be examined to make sure there are no leaks after the charging operation and before commissioning. A follow-up leak test must be carried out before leaving the site.

Dismantling

- Before dismantling, the technician must familiarise himself/herself with the equipment and its specifications. We highly recommend carefully recovering all refrigerants. Before this, oil and refrigerant samples must be taken if analyses are to be carried out before any other use of the recovered refrigerant. Check for the presence of a power supply before starting work.

1. Familiarise yourself with the equipment and how it operates.
2. Electrically isolate the system.
3. Before starting work, check the following points:
 - mechanical handling equipment is available if needed to handle the refrigerant cylinders;
 - all personal protective equipment is available and used correctly;
 - the recovery process is followed at all times by a cognizant person;
 - the recovery cylinders and equipment comply with the relevant standards.

1. Drain the cooling system where possible.
2. If a vacuum cannot be created, install a manifold in order to be able to remove the refrigerant from various locations within the system.
3. Make sure that the cylinder is located on the scales before starting recovery operations.
4. Start the recovery unit and operate as per its instructions.
5. Do not overfill the cylinders (no more than 80% of the volume must be filled with liquid).
6. Do not exceed the maximum working pressure of the cylinder, even temporarily.
7. When the cylinders have been filled correctly and the process is complete, check that the cylinders and the equipment are quickly removed from the site and that the alternative shut-off valves on the equipment are closed.
8. The recovered refrigerant must not be charged in another cooling system, unless it has been cleaned and inspected.

TROUBLESHOOTING

- All brazing must be carried out by qualified brazers.
- Replacement pipes must always be made of copper in compliance with standard NF EN 12735-1.
- Leak detection; pressure test:
 - never use oxygen or dry air, risk of fire or explosion,
 - use dry nitrogen or the mixture of nitrogen and refrigerant indicated on the information plate,
- the test pressure for both the high and low pressure circuits must not exceed 42 bar in cases where the appliance is equipped with the optional pressure gauge.
- The high pressure circuit pipes are made of copper and have a diameter equal to or greater than 1"5/8. A certificate as indicated in §2.1 in compliance with standard NF EN 10204 must be requested from the supplier and filed in the installation's technical file.
- Technical data relative to the safety requirements of the various applicable directives are indicated on the information plate. All this information must be recorded in the appliance's installation manual, which must be kept in its technical file: model, code, serial number, maximum and minimum OT, OP, year of manufacture, CE marking, manufacturer's address, refrigerant and weight, electrical parameters, thermo-dynamic and acoustic performance.

LABELLING

- The equipment must be labelled so as to specify that it is out of order and that the refrigerant has been drained.
- The label must be dated and signed.
- For appliances containing a flammable refrigerant, check that labels are placed on the equipment stating that it contains a flammable refrigerant.

RECOVERY

- When draining the refrigerant for maintenance or decommissioning, best practices should be followed in order to safely drain all of the refrigerant.
- When transferring refrigerant to a cylinder, make sure that you use a recovery cylinder that is compatible with the refrigerant. Make sure that the correct number of cylinders are provided for recovering all of the refrigerant. All cylinders used must be intended for the recovery of refrigerant and must be labelled for this specific refrigerant. The cylinders must be equipped with a vacuum valve and a stop gate in good working order. Empty collection cylinders are drained and, where possible, cooled before recovery.
- The recovery equipment must be in good working order, the instructions for using the equipment must be within reach and the equipment must be compatible for use with the refrigerant concerned, including, where appropriate, a flammable refrigerant. Moreover, a set of calibrated scales must be available and in good working order. The pipework must be complete, have no leaks or disconnected connectors, and must be in good condition. Before using the recovery unit, check that it is in good working order, that it has been well maintained and that the associated electric components are sealed so as to prevent any risk of fire in the event of refrigerant being released. If you have any doubts, contact the manufacturer.
- The recovered refrigerant must be sent to the refrigerant supplier in its recovery cylinder with a waste transfer note. Do not mix different refrigerants in the recovery units, and in particular in the cylinders.
- If the compressor has been removed or if oil from the compressor has been drained, check that the refrigerant has been completely removed to prevent it from mixing with the lubricant. The draining process must be carried out before returning the compressor to the supplier. Only the electric heater of the compressor body can be used to accelerate this process. This operation can be carried out safely once all liquids within the system have been drained.

RECYCLING



This symbol is required by the European directive DEEE 2012/19/EU (directive on waste electrical and electronic equipment) and means that your appliance must not be thrown into a normal bin. It will be selectively collected for the purpose of reuse, recycling or transformation. If it contains any substances that may be harmful to the environment, these will be eliminated or neutralised. Contact your retailer for recycling information.

FSP ON/OFF +7°C

User and Service manual

INDEX

1. Specifications
2. Dimension
3. Installation and connection
4. Accessories
5. Electrical Wiring
6. Display Controller Operation
7. Troubleshooting
8. Exploded Diagram
9. Maintenance

Thank you for using our swimming pool heat pump for your pool heating, it will heat your pool water and keep the constant temperature when the air ambient temperature is between 7 and 43°C

▲ ATTENTION: This manual includes all the necessary information with the use and the installation of your heat pump.

The installer must read the manual and attentively follow the instructions in implementation and maintenance. Please keep on pass on this manual for later throughout the appliance 's service life.

The installer is responsible for the installation of the product and should follow all the instructions of the manufacturer and the regulations in application. Incorrect installation against the manual implies the exclusion of the entire guarantee.

The manufacturer declines any responsibility for the damage caused with the people, objects and of the errors due to the installation that disobey the manual guideline. Any use that is without conformity at the origin of its manufacturing will be regarded as dangerous.

1. Specifications

1.1 Technical data




MODEL		74139	74140	74141	74142
Code		FSP-05	FSP-08	FSP-11	FSP-14
* Performance at Air 28°C, Water 28°C, Humidity 80%					
Heating capacity	kW	5	7.5	11	14
Power consumption	kW	1.00	1.40	2.20	2.60
C.O.P.		5	5.4	5	5.4
* Performance at Air 15°C, Water 26°C, Humidity 70%					
Heating capacity	kW	3.5	5.5	7.5	9.5
Power consumption	kW	0.9	1.3	1.8	2.3
C.O.P.		4	4.4	4.3	4.2
* General data					
Compressor type		Rotary/R32			
Voltage	V	220-240V/50Hz/1PH			
Rated current	A	4.4	6.2	9.8	11.5
Minimum fuse	A	12	17	27	32
Advised water flux	m ³ /h	2.5~3.2	2.5~4.2	3.5~7.1	4~7.9
Water pressure drop	Kpa	12	12	15	15
Heat exchanger		Twist-Titanium tube in PVC			
Water connection	mm	50			
Fan quantity		1			
Ventilation type		Horizontal			
Noise level(10m)	dB(A)	32	33	37	37
Noise level(1m)	dB(A)	50	51	54	54
Refrigerant (R32)	g	400	450	800	900
CO2 equivalent	Tonne	0.27	0.31	0.54	0.61
* Dimension/ Weight					
Net weight	kg	36	46	52	77
Gross weight	kg	38	48	54	81
Net dimension	mm	799.5*330*523.6	977.6*386*571.5		1102.3*410*703.7
Packing dimension	mm	875*345*563	1055*402*610		1125*485*725

* Above data are subjects to modification without notice.




2. Dimension

Model:FSP-05




unit:mm



Model:FSP-08 / FSP-11



Model:FSP-14



3. Installation and connection

3.1 Notes

The factory supplies only the heat pump. All other components, including a bypass if necessary, must be provided by the user or the installer.

Attention:

Please observe the following rules when installing the heat pump:

1. Any addition of chemicals must take place in the piping located **downstream** from the heat pump.
2. Install a bypass if the water flow from the swimming pool pump is more than 20% greater than the allowable flow through the heat exchanger of the heat pump.
3. Install the heat pump above the water level of the swimming pool.
4. Always place the heat pump on a solid foundation and use the included rubber mounts to avoid vibration and noise.
5. Always hold the heat pump upright. If the unit has been held at an angle, wait at least 24 hours before starting the heat pump.


3.2 Heat pump location

The unit will work properly in any desired location as long as the following three items are present:

- 1. Fresh air – 2. Electricity – 3. Swimming pool filters**

The unit may be installed in virtually any **outdoor** location as long as the specified minimum distances to other objects are maintained (see drawing below). Please consult your installer for installation with an indoor pool. Installation in a windy location does not present any problem at all, unlike the situation with a gas heater (including pilot flame problems).

ATTENTION: Never install the unit in a closed room with a limited air volume in which the air expelled from the unit will be reused, or close to shrubbery that could block the air inlet. Such locations impair the continuous supply of fresh air, resulting in reduced efficiency and possibly preventing sufficient heat output. See the drawing below for minimum dimensions.




3.3 Distance from your swimming pool


The heat pump is normally installed within a perimeter area extending 7.5 m from the swimming pool. The greater the distance from the pool, the greater the heat loss in the pipes. As the pipes are mostly underground, the heat loss is low for distances up to 30 m (15 m from and to the pump; 30 m in total) unless the ground is wet or the groundwater level is high. A rough estimate of the heat loss per 30 m is 0.6 kWh (2,000 BTU) for every 5 °C difference between the water temperature in the pool and the temperature of the soil surrounding the pipe. This increases the operating time by 3% to 5%.

3.4 Check-valve installation

Note: If automatic dosing equipment for chlorine and acidity (pH) is used, it is essential to protect the heat pump against excessively high chemical concentrations which may corrode the heat exchanger. For this reason, equipment of this sort must always be fitted in the piping on the **downstream** side of the heat pump, and it is recommended to install a check-valve to prevent reverse flow in the absence of water circulation. Damage to the heat pump caused by failure to observe this instruction is not covered by the warranty.




3.5 Typical arrangement



Note: This arrangement is only an illustrative example.

3.6 Adjusting the bypass



Please take below steps to adjust the by-pass:

1. Valve 1 wide open. Valve 2 & valve 3 closed.
2. Slowly open valve 2 & valve 3 by half, then close the valve 1 slowly to increase the water flow to valve 2 & valve 3.
3. If it shows 'ON' or 'EE3' on display, it means the water flow into heat pump is not enough, then you need adjust the valves to increase the water flow through the heat pump.

How to get the optimum water flow.

Please turn on the heat pump under heating function, firstly close the by-pass then open it slowly to start the heat pump (the machine can't start running when the water flow is insufficient)

Continue to adjust the by-pass, at the meantime to check the Inlet water temp. & Outlet water temp., it will be optimum when the difference is around 2 degree.

3.7 Electrical connection

Note: Although the heat pump is electrically isolated from the rest of the swimming pool system, this only prevents the flow of electrical current to or from the water in the pool. Earthing is still required for protection against short-circuits inside the unit. Always provide a good earth connection. The installer must consult the electricity provider if necessary and ensure that the equipment is connected correctly to an electricity network with impedance under 0.095 ohm.


Warning : Before any work inside the appliance, you must cut the appliance's electricity supply as there is a risk of electric shock which may cause material damage, serious injury or even death.

- Incorrectly tightened terminals may cause the terminal box to heat up, which can invalidate the warranty.
- Only a qualified and experienced technician is authorised to carry out cabling work within the appliance or to replace the power cord.

Before connecting the unit, verify that the supply voltage matches the operating voltage of the heat pump. It is recommended to connect the heat pump to a circuit with its own fuse or circuit breaker (slow type; curve D) and to use adequate wiring.

Connect the electrical wires to the terminal block marked ' POWER SUPPLY '.


A second terminal block marked 'WATER PUMP ' is located next to the first one. The filter pump (max. 5 A 0 V) can be connected to the second terminal block here. This allows the filter pump operation to be controlled by the heat pump.



3.8 Initial operation

Note: In order to heat the water in the pool (or hot tub), the filter pump must be running to cause the water to circulate through the heat pump. The heat pump will not start up if the water is not circulating.

After all connections have been made and checked, carry out the following procedure:

1. Switch on the filter pump. Check for leaks and verify that water is flowing from and to the swimming pool.
2. Connect power to the heat pump and press the On/Off button  on the electronic control panel. The unit will start up after the time delay expires (see below).
3. After a few minutes, check whether the air blowing out of the unit is cooler.
4. When turn off the filter pump , the unit should also turn off automatically , if not, then adjust the flow switch.
5. Allow the heat pump and the filter pump to run 24 hours a day until the desired water temperature is reached. The heat pump will stop running at this point. After this, it will restart automatically (as long as the filter pump is running) whenever the swimming pool water temperature drops 2 degree below the set temperature.

Depending on the initial temperature of the water in the swimming pool and the air temperature, it may take several days to heat the water to the desired temperature. A good swimming pool cover can dramatically reduce the required length of time.

Water Flow Switch:

It is equipped with a flow switch for protecting the HP unit running with adequate water flow rate .It will turn on when the pool pump runs and shut it off when the pump shuts off.

Time delay - The heat pump has a built-in 3-minute start-up delay to protect the circuitry and avoid excessive contact wear. The unit will restart automatically after this time delay expires. Even a brief power interruption will trigger this time delay and prevent the unit from restarting immediately. Additional power interruptions during this delay period do not affect the 3-minute duration of the delay.

3.9 Condensation

The air drawn into the heat pump is strongly cooled by the operation of the heat pump for heating the pool water, which may cause condensation on the fins of the evaporator. The amount of condensation may be as much as several litres per hour at high relative humidity. This is sometimes mistakenly regarded as a water leak.

4. Accessories**4.1 Accessories list**


 <p>Anti-vibration base, 4 pcs</p>	 <p>Draining jet, 2 pcs</p>
 <p>Winter cover, 1pc</p>	 <p>Water drainage pipes, 2 pcs</p>

4.2 Accessories Installation



Anti-vibration bases


1. Take out 4 Anti-vibration bases
2. Put them one by one on the bottom of machine like the picture.



Draining jet


1. Install the draining jet under the bottom panel
2. Connect with a water pipe to drain out the water.

Note: Lift the heat pump to install the jet. Never overturn the heat pump, it could damage the compressor.



Water Inlet & outlet junction

1. Install the two joints like the picture shows
2. Screw them onto the water Inlet & outlet junction



Cable wiring


1. Open the cover of the electric box
2. Fix the power supply wire on joints L N E




Water pump wiring (Dry contact)

1. Open the cover of the electric box
2. With the connector 1 and 2 you can pilot the water filtration through the timer of the filtration (dry contact)

Dry contact timer connection Timer




Dry contact pump connection



5. Electrical Wiring

5.1 SWIMMING POOL HEAT PUMP WIRING DIAGRAM

FSP-05 / FSP-08 / FSP-11



FSP-05:

C1 = Fan Motor capacitor value = 2uF/450V

C2 = Compressor capacitor Value = 35uF/450V

FSP-08 :

C1 = Fan Motor capacitor value = 2uF/450V


C2 = Compressor capacitor Value = 40uF/450V

FSP-11:

C1 = Fan Motor capacitor value = 2uF/450V

C2 = Compressor capacitor Value = 60uF/450V

FSP-14



FSP-14:

C1 = Fan Motor capacitor value = 6uF/450V

C2 = Compressor capacitor Value = 65uF/450V

NOTE:


(1) Above electrical wiring diagram only for your reference, it is subjected to the wiring diagram posted on the machine.

(2) The swimming pool heat pump must be connected ground wire well, although the unit heat exchanger is electrically isolated from the rest of the unit. Grounding the unit is still required to protect you against short circuits inside the unit. Bonding is also required.


Disconnect: A disconnect means (circuit breaker, fused or un-fused switch) should be located within sight of and readily accessible from the unit. This is common practice on commercial and residential heat pumps. It prevents remotely-energizing unattended equipment and permits turning off power at the unit while the unit is being serviced.

6. Operation


(1) Guide for operation






(2) Start the pool heat pump

Press  to start the heat pump, the LED display will show the inlet water temperature and current working mode after 5s.

(3) Stop the pool heat pump

Press  once again to stop the heat pump, the LED display shows 'OFF'




(4) Water temperature setting

Press  or  to set the desired water in temperature in current working mode, then Press  to save setting and exit.




(5) TIME setting

Press  button ,then press  to enter into " TIME " display ;






** HOUR SETTING**

Press  again to "HOUR" setting , "HH" flashed ,then press  or  to adjust the HOUR from 0 to 23 ;






MINUTE SETTING

Press  to enter into MINUTE setting ,"MM" flashed , then press  or  to adjust the MINUTE from 0 to 59.

(6) TIMER ON Setting



Press  button ,then press  button twice to enter into TIMER ON setting .When you see the starting time displaying on controller ,Press  to confirm to enter into TIMER ON setting interface , finally press  or  to adjust the starting time.

(7) TIMER OFF Setting

Press  button ,then press  button 3 times to enter into " TIME OFF" setting . When you see the stopping time displaying on controller ,Press  to confirm to enter into TIMER OFF setting interface , finally press  or  to adjust the stopping time .




****Above operations, you could press  button to save the setting and quick-exit the program. ****

(8) How to check the parameters?

Press  button ,then press  to check the parameter of B - C - D - E- F- G .

Code	Parameter	Range
B	Water in temperature	-9 to 99°C
C	Water out Temperature	-9 to 99°C
D	Heating pipe temperature	-29 to 99°C
E	Gas return temperature	-29 to 99°C
F	Ambient temperature	-29 to 99°C
H	Actual steps of Electronic expansion valve	N*5











** ATTENTION **

When you press  and press  button to enter into parameter checking , the  button could not be operated.

At the same as above ,when you press  and press  button to check TIME - starting time of TIMER and Stopping time of TIMER ,the  could be not operated.



(9) Parameter setting

This part should be operated only by qualified technicians for after-service or maintenance.

- (1) Press  +  +  at same time in 5 second, display flashes ,
- (2) Press  or  to choose the parameter you want to adjust
- (3) Press  again to enter into interface
- (4) Press  or  to adjust the value setting.
- (5) Finally press  once again to save the data or press  to save and quick-exit the parameter setting .

Parameter	Meaning	Range	Default	Remarks
1	To set the entering water temp. under heating mode	15-42°C	28°C	Adjustable
2	Entry into defrosting time period	30-90MIN	40MIN	Adjustable
3	Terms of Entry defrosting function	-30°C to0°C	-7°C	Adjustable
4	Terms of Exit defrosting	2 to 30°C	20°C	Adjustable
5	Time of Exit defrosting	1 to 12MIN	12MIN	Adjustable
6	Mode: 0 Heat	0	0	Not adjustable
7	Mode selection of Electronic expansion valve	0-1	1(auto)	Adjustable
A	Manual adjustment steps of electronic expansion valve	18-94	70	Adjustable
L	Entering water temperature calibration	-9.9-9.9	0	Adjustable

Recover to Factory default setting

















Long press  and  simultaneously in 10 second to recover to factory default setting ,it will display "0000" and then back to "OFF".

7. Troubleshooting

7.1 Error code display on LED wire controlle

Malfunction	Error code	Reason	Solution
Low ambient temperature protection	PP0	Ambient temperature is too low	
Inlet water temperature sensor failure	PP1	The sensor in open or short circuit	Check or change the sensor
Outlet water temperature sensor failure	PP2	The sensor in open or short circuit	Check or change the sensor
Heating condenser sensor failure	PP3	The sensor in open or short circuit	Check or change the sensor
Gas return sensor failure	PP4	The sensor in open or short circuit	Check or change the sensor
Ambient temperature sensor failure	PP5	The sensor in open or short circuit	Check or change the sensor
Temperature difference too much protection water inlet and outlet	PP6	Water flow volume is not enough	Check the water flow volume or water jammed or not.
First grade antifreeze protection in Winter	PP7	Ambient temperature or water inlet temperature is too low	Water pump will run automatically for first grade antifreeze
Second grade antifreeze protection in Winter	PP7	Ambient temperature or water inlet temperature is too low	Heat pump will start heating for second grade antifreeze
High pressure protection	EE1	1. Refrigerant is too much 2. Water flow in not enough	1. Discharge redundant refrigerant from HP gas system 2. Clean the air exchanger
Low pressure protection	EE2	1. Refrigerant is not enough 2. Filter jammed or capillary jammed	1. Check if there is any gas leakage, re-fill the refrigerant 2. Clean the air exchanger 3. Replace the filter or capillary
Flow switch opened	ON /EE3	Low water flow, wrong flow direction, or flow switch failure or the flow switch can be mounted in the bad way	Check if the water flow is enough and flow in right direction, or else the flow switch could be failed.
Inlet and outlet water temperature difference malfunction	EE5	Water flow rate is not enough, water pressure difference is too low	Check the water flow rate or water system is jammed or not
Communication failure	EE8	Wire connection is not good	Check the wire connection

7.2 Malfunction display on PCB





Protection /Malfunction	Controller display	Malfunction light display on PCB
Heat pump standby status	ON	
Heat pump running	Water in temperature	
Low ambient temperature protection	PP0	
Inlet water temperature sensor failure	PP1	
Outlet water temperature sensor failure	PP2	
Heating condenser sensor failure	PP3	
Gas return sensor failure	PP4	
Ambient temperature sensor failure	PP5	
Temperature difference too much protection between water inlet and outlet	PP6	
First grade antifreeze protection in Winter	PP7	
Second grade antifreeze protection in Winter	PP7	
High pressure protection	EE1	
Low pressure protection	EE2	
Flow switch closed	ON/EE3	
Inlet and outlet water temperature difference malfunction	EE5	
Defrosting	Defrosting	

7.3 Other Malfunctions and Solutions (No display on LED wire controller)

Malfunctions	Observing	Reasons	Solution
Heat pump is not running	LED wire controller no display.	No power supply	Check cable and circuit breaker if it is connected
	LED wire controller displays the actual time.	Heat pump under standby status	Startup heat pump to run.
	LED wire controller displays the actual water temperature.	<ol style="list-style-type: none"> 1. Water temperature is reaching to setting value, HP under constant temperature status. 2. Heat pump just starts to run. 3. Under defrosting. 	<ol style="list-style-type: none"> 1. Verify water temperature setting. 2. Startup heat pump after a few minutes. 3. LED wire controller should display "Defrosting".
Short running	LED displays actual water temperature, no error code displays.	<ol style="list-style-type: none"> 1. Fan NO running. 2. Air ventilation is not enough. 3. Refrigerant is not enough. 	<ol style="list-style-type: none"> 1. Check the cable connections between the motor and fan, if necessary, it should be replaced. 2. Check the location of heat pump unit, and eliminate all obstacles to make good air ventilation. 3 Replace or repair the heat pump unit.
Water stains	Water stains on heat pump unit or condensate from heat pump.	<ol style="list-style-type: none"> 1. Concreting. 2. Water leakage from the heat exchanger. 	<ol style="list-style-type: none"> 1. No action. 2. Check the titanium heat exchanger carefully if it is any defect.
Too much ice on evaporator	Too much ice on evaporator.	<ol style="list-style-type: none"> 1. Refrigerant is not enough 2. Filter jammed or capillary jammed 	<ol style="list-style-type: none"> 1. Check the location of heat pump unit, and eliminate all obstacles to make good air ventilation. 2. Replace or repair the heat pump unit.

8. Exploded Diagram




Model: FSP-05



Spare parts list: FSP-05

NO	ERP	Spare parts	NO	ERP	Spare parts
1	133420003	Top cover	28	112200141	Ambient temp. sensor T5
2	108920005	Fan motor bracket support	29	113090085	Exchanger to Capillary
3	108920011	Pillar	30	113010409	Discharge pipe
4	108920002	Fan motor bracket	31	113020563	Gas return piping
5	103000250	Evaporator	32	112100030	High pressure switch
6	108920009	Isolation panel	33	112100046	Low pressure switch
7	112000033	Fan motor	34	120000098	Gas valve
8	132000001	Fan blade	35	101000241	Compressor
9	108920008	Front panel	36	112200138	Water outlet temp. sensor T2
10	112200136	Evaporator temperature sensor T3	37	108010025	Exchanger temperature sensor clip
11	113190007	Clip	38	133020026	Rubber ring on water connection
12	113190001	Sensor holder	39	112200133	Water inlet temp. sensor T1
13	108020068	Fan grill	40	102050004	Water connection sets
14	102041042	Titanium heat exchanger	41	133020037	Blue rubber ring
15	108920016	Base tray	42	133020012	Red rubber ring
16	108920007	Side panel	43	112100021	Water flow switch
17	110000039	Cable gland	44	108020044	Electric box cover
18	136020134	Rubber ring	45	112200064	Transformer
19	106000011	Pressure gauge	46	108010008	Capacitor clip
20	103000250	Evaporator pipe	47	111300013	Compressor capacitor
21	103000250	Distribution piping	48	111300002	Fan capacitor
22	133020004	Controller box cover	49	108020040	Electric box
23	117020074	Controller	50	117010055	PCB
24	133020030	Control box	51	136010004	Clip
25	133020002	Waterproof box	52	115000060	2-ways terminal block
26	108920010	Back panel	53	115000002	3-ways terminal block
27	133020010	Ambient temp. sensor clip			

Model: FSP-08 / FSP-11







Spare parts list: FSP-08

NO	ERP	Spare parts	NO	ERP	Spare parts
1	133430002	Top cover	29	113190001	Clip
2	108900016	Fan motor bracket support	30	108900020	Back panel
3	108900021	Pillar	31	133020010	Ambient temp. sensor clip
4	108900011	Fan motor bracket	32	112200141	Ambient temp. sensor T5
5	103000311	Evaporator	33	101000219	Compressor
6	108900010	Isolation panel	34	112100046	Low pressure switch
7	112000069	Fan motor	35	120000097	Gas valve
8	132000010	Fan blade	36	113020564	Gas return piping
9	113190007	Sensor holder	37	113020609	Discharge pipe
10	112200136	Evaporator temperature sensor T3	38	112100030	High pressure switch
11	103000311	Distribution piping	39	113090090	Exchanger to Capillary
12	103000311	Evaporator pipe	40	108140063	Electric box cover
13	108010102	Fan grill	41	111000014	Compressor capacitor
14	108900018	Front panel	42	108010007	Capacitor clip
15	108900001	Base tray	43	112200064	Transformer
16	108900019	Side panel	44	108140061	Electric box
17	110000039	Cable connector	45	108140062	Electric box board
18	136020134	Rubber ring	46	117010055	PCB
19	106000011	Pressure gauge	47	111300002	Fan capacitor
20	102041043	Titanium heat exchanger	48	112200138	Water outlet temp. sensor T2
21	133020030	Control box	49	108010025	Exchanger temperature sensor clip
22	133020002	Waterproof box	50	133020026	Rubber ring on water connection
23	133020004	Controller box cover	51	133020012	Red rubber ring
24	108030241	Wiring box support plate	52	102050015	Water connection sets
25	108030240	Wiring box	53	133020011	Blue rubber ring
26	136010004	Clip	54	112200133	Water inlet temp. sensor T1
27	115000060	2-ways terminal block	55	112100021	Water flow switch
28	115000002	3-ways terminal block			

Spare parts list: FSP-11

NO	ERP	Spare parts	NO	ERP	Spare parts
1	133430002	Top cover	29	113190001	Clip
2	108900016	Fan motor bracket support	30	108900020	Back panel
3	108900021	Pillar	31	133020010	Ambient temp. sensor clip
4	108900011	Fan motor bracket	32	112200141	Ambient temp. sensor T5
5	103000310	Evaporator	33	101000219	Compressor
6	108900010	Isolation panel	34	112100046	Low pressure switch
7	112000069	Fan motor	35	120000097	Gas valve
8	132000010	Fan blade	36	113020526	Gas return piping
9	113190007	Sensor holder	37	113010378	Discharge pipe
10	112200136	Evaporator temperature sensor T3	38	112100030	High pressure switch
11	103000310	Distribution piping	39	113090090	Exchanger to Capillary
12	103000310	Evaporator pipe	40	108140063	Electric box cover
13	108010102	Fan grill	41	111000014	Compressor capacitor
14	108900018	Front panel	42	108010007	Capacitor clip
15	108900001	Base tray	43	112200064	Transformer
16	108900019	Side panel	44	108140061	Electric box
17	110000039	Cable connector	45	108140062	Electric box board
18	136020134	Rubber ring	46	117010055	PCB
19	106000011	Pressure gauge	47	111300002	Fan capacitor
20	102041043	Titanium heat exchanger	48	112200138	Water outlet temp. sensor T2
21	133020030	Control box	49	108010025	Exchanger temperature sensor clip
22	133020002	Waterproof box	50	133020026	Rubber ring on water connection
23	133020004	Controller box cover	51	133020012	Red rubber ring
24	108030241	Wiring box support plate	52	102050015	Water connection sets
25	108030240	Wiring box	53	133020011	Blue rubber ring
26	136010004	Clip	54	117110008	Water inlet temp. sensor T1
27	115000060	2-ways terminal block	55	112100021	Water flow switch
28	115000002	3-ways terminal block			

Model: FSP-14



Spare parts list: FSP-14

NO	ERP	Spare parts	NO	ERP	Spare parts
1	133410001	Top cover	31	108050195	Back panel
2	108050208	Fan motor bracket support	32	112200141	Ambient temp. sensor T5
3	108050132	Pillar	33	133020010	Ambient temp. sensor clip
4	108050207	Fan motor bracket	34	113010281	Discharge pipe
5	103000201	Evaporator	35	112100030	High pressure switch
6	108110039	Isolation panel	36	112100046	Low pressure switch
7	112000070	Fan motor	37	120000097	Gas valve
8	113600010	Fan blade	38	101000218	Compressor
9	103000201	Distribution piping	39	113110001	Oil-pressure pipe
10	112200136	Evaporator temperature sensor T3	40	113100013	Transition pipe
11	113190007	Clip	41	113020543	Gas return piping
12	113190001	Sensor holder	42	113090066	Exchanger to Capillary
13	102040993	Titanium heat exchanger	43	112200138	Water outlet temp. sensor T2
14	108050162	Fan grill	44	108010025	Exchanger temperature sensor clip
15	108050135	Front panel	45	112200133	Water inlet temp. sensor T1
16	103000201	Evaporator pipe	46	102050005	Water connection sets
17	108050172	Base tray	47	102050005	Water connection
18	108050206	Side panel	48	133020011	Blue rubber ring
19	106000011	Pressure gauge	49	133020012	Red rubber ring
20	110000039	Cable connector	50	133020026	Rubber ring on water connection
21	136020119	Rubber ring	51	112100021	Water flow switch
22	133020004	Controller box cover	52	108110011	Electric box cover
23	117020074	Controller	53	108010007	Capacitor clip
24	133020030	Control box	54	111000039	Compressor capacitor
25	133020002	Waterproof box	55	117010045	PCB
26	108030241	Wiring box support plate	56	112200064	Transformer
27	108030240	Wiring box	57	108050192	Electric box
28	115000060	2-ways terminal block	58	108050193	Electric box board
29	136010004	Clip	59	111000006	Fan capacitor
30	115000002	3-ways terminal block	60	104000001	AC contactor

9. Maintenance

Warning !

-Before any maintenance work on the appliance, you must cut the electricity supply as there is a risk of electric shock which may cause material damage, serious injury or even death.

- It is recommended that the appliance undergo general servicing at least on a yearly basis to ensure its proper operation, maintain performance levels and prevent any possible failures. These operations are carried out at the user's expense, by a qualified technician. For maintenance to be carried out by a qualified technician.

-for maintenance to be carried out by a qualified technician, please read the safety instructions in the previous pages provided in the chapter entitled "maintenance: warnings concerning appliances containing R32 refrigerant" before performing any of the maintenance operations described below.

(1) You should check the water supply system regularly to avoid the air entering the system and occurrence of low water flow, because it would reduce the performance and reliability of HP unit.

(2) Clean your pools and filtration system regularly to avoid the damage of the unit as a result of the dirty or clogged filter.

(3) In another way, you should check the unit is water fully before the unit starts to run again.

(4) After the unit is conditioned for the winter season, it's recommended to cover the heat pump with special winter cover.

(5) When the unit is running, there is all the time a little water discharge under the unit.

(6) R32 pressure and temperature mapping table

Condition	Power OFF			
	-5- 5 °C	5-15 °C	15-25 °C	25-35°C
Ambient Temperature	-5- 5 °C	5-15 °C	15-25 °C	25-35°C
Water temperature	/	/	/	/
Pressure gauge reading	0.68-0.93 MPa	0.93-1.25 MPa	1.25-1.64 MPa	1.64-2.1 MPa

(7) Please always empty the water in heat pump during winter time or when the ambient temperature drops below 0°C, or else the Titanium exchanger will be damaged because of being frozen, in such case, your warranty will be lost.